

Tools required:
Phillips head screwdriver or #2 Square drive bit

Parts Included:
(4) #10 x 1 1/4" Long Phillips Drive Pan Head Machine Screws

- I** Position SAM-3 on indicated holes (See pict. A).
Attach assembly to the underside of
worksurface using the #10 x 1 1/4" screws (4).

Attach first (2) two screws into SAM-3 puck.
Rotate puck 90 degrees and install and
fasten last (2) screws (See Pict. B).

