

Tools Required:
Phillips Head Screwdriver

Parts Included:
(4) #10-24 x 1 ¼" Flat Head Phillips Drive Screw
(1) Barcode Holder

- 1 Align the barcode holder (provided) to the specified 4 specified hole placements beneath the work surface (see figure A). Position and rotate the barcode holder so the 4 screws (provided) can secure the barcode holder to the underside of the work surface.




Figure A

If you have any questions, contact Altus at service@altus-inc.com or (616) 233-9530. If immediate assistance is needed, please call as soon as possible so we may help.